FV0006

OPTAC Fleet Viewer v5
Import from the OPTAC Download Tool

Description: How to import from the OPTAC Download Tool

Product: OPTAC Fleet Viewer v5

REQUIREMENTS:

- ✓ OPTAC Fleet Viewer v5 installed on a computer that meets the System Requirements
- ✓ OPTAC software license key connected to computer
- ✓ OPTAC Download Tool
- ✓ USB Cable

PURPOSE:

This guide demonstrates how to import your digital data from the OPTAC Download Tool to the OPTAC Fleet Viewer Software.

EXPLANATION:

1. Switch on the OPTAC Download Tool by holding the On/Off button for three seconds. This button is located on the right-hand side of the tool.

Figure 1

2. Connect the OPTAC Download Tool to your PC using the USB cable.

Figure 2

3. Double click on the OPTAC Fleet Viewer icon on your desktop to open the software.

Figure 3

4. Log into the software by entering your Username and Password and clicking 'Login'.

Figure 4

5. Click on the 'Data Centre' icon.

Figure 5

6. Select the 'OPTAC Download Tool' option and click 'Next'.

Figure 6

7. Once the OPTAC Download Tool has been detected click 'Next'.

Figure 7

8. Select the 'Legal File Extensions' option and click 'Next'.

Figure 8

9. Select the Driver/Vehicle downloads to be imported and click 'Next'.

Figure 9

10. Select the 'Yes' option allow OPTAC to delete the data from the OPTAC Download Tool once successfully imported. Click 'Next' to start the import process.

Figure 10

11. Once the import process has completed click 'Finish' to close the import screen.

Figure 11